

Magnetic Window System Sizes 75 x 75, 105 x 105 and 150 x 150 Fitting Instructions

1. Measure your window opening. Allow for an overlap of at least 15mm-20mm all the way around the frame to make fitting easier.
2. Cut the four lengths of the plastic frame with a Junior hacksaw, or similar.
3. Insert the frame lengths into the corners to make the window frame.
4. Now overlay the flyscreen material and don't forget to insert the string pull handle into the corner where you want to pull your frame away from the window to open or close it.
5. Press the magnetic strip firmly into the groove (You may be able to cut the magnet length with very strong scissors) to hold the material in place.
6. Once you have finished the frame and are happy, cut off excess flyscreen material.
7. Let the flat magnet attach itself to the frame. Peel off the protective strip on the flat magnet and apply the whole frame to the window. This is the best way ensure that the magnets line up perfectly.
8. Optionally you can place the two self adhesive metal clips at either end of the top of the frame.