

**Montage instructie**  
**Instruction de montage**

*Flyscreen Queen*  
 Keeping Bugs out of Britain's Homes

- 1** Opmeten van de opening  
 Vermessung der Öffnung  
 Measure the opening  
 Mesurer l'ouverture  
 Medir la abertura  
 Medir la abertura
- 2** Profiel inkorten  
 Profil abkürzen  
 Shortening of the moulding  
 Raccourcir le profil  
 Acortar el perfil  
 Diminuir o perfil
- 3** Lamel op profiel bevestigen  
 Lamelle am Profil befestigen  
 Fix strip to profile section  
 Fixer la lamelle sur le profil  
 Fijar la tela al marco  
 Fixar a lamela sobre o perfil
- 4** Schroeven bevestigen  
 Schrauben befestigen  
 Tighten screws  
 Fixer les vis  
 Apriete los tornillos  
 Fixar os parafusos
- 5** Controleren  
 Prüfen  
 Check  
 Contrôler  
 Compruébelo todo  
 Controlar
- 6** Overtollig gaas afsnijden  
 Überflüssige Drahtgaze abschneiden  
 Cut off surplus netting  
 Découper la toile excédentaire  
 Cortar la tela sobrante  
 Cortar o excesso de gaze

